

From COM Genius to CLASSIC OnDemand

For the programming of the new OnDemand blanks you need only 3 things:

1. One OnDemand blank
2. The OnDemand USB-cable
3. The OnDemand program software

German version can be found on page 1.

To 1. OnDemand blank

Depending on the model type there are 3 different OnDemand blank:

TV1

For older TV models
Article: 9 43 87 57



STB1

For set-top boxes
Article: 69 45 33



DTV1

For Flat-TV
Article: 6 13 19 56



To 2. OnDemand USB cable

You need a special USB cable for the OnDemand blank.

USB cable
OnDemand
Article: 6057779



To 3. OnDemand program software

You need a special Windows program software for programming the OnDemand Blanks.

The program software you could download in the ASWO Shop e.g. at Article-No. D264725 or at every Classic IRC-OD remote control.

CLASSIC Remote Controls


Classic On-Demand

You can program this remote control immediately by using a Classic DTV1 blank yourself.


IRC-Code: **87001**

[Download keyboard layout as PDF](#)

You need the following equipment to program:

 **Classic DTV1 blank**
article number 6131956

+

 **Cable IRC-OD**
article number 6057779

How does it work exactly?

1. Please install the Classic Software (one time) [Link to program download \(details\)](#)
2. Please click on your desktop on the shortcut "Classic IRC-OD Programmer" and enter the five-digit code at the opened window. [\(details\)](#)
3. Follow the instructions at the Classic IRC-OD Programmer [\(details\)](#)



Operating- and installation instructions for the program software you can find on Article-No. D256346.