

EM-303

Conductor and board cleaner

Concentrate for ultrasonic cleaner

Properties:

EM-303 removes resin flux agents on equipped, unequipped and misprinted PCBs/hybrids. Cleans solder frames, unsoldered solder pasts, grease, fingerprints and oils. Quick and material-protecting cleaning is warranted at proper application.

Application:

Dosing depends on the degree of soiling and filling volume: Depending on degree of contamination: 10% EM-303 for 1-3 min at 60-70°C. Ensure complete wetting of the cleaned goods. Upon completion: Flush cleaned goods thoroughly with demineralized water.

Composition:

<5% phosphonate, 0.5-2% sodium hydroxide, carbonate, <5% silicare, ammonia biodegradable, alkaline. pH-value of the 1% solution: 10.7%.

Marking according to hazardous substance regulation:

H318 Causes serious eye damage. H315 Causes skin irritation. P280 Wear protective gloves/protective clothing/eye protection/face protection. P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.



Article: 61008

Available in 500ml bottles