

## EM-404

### Concentrate Aluminium and pressure-casting

#### Concentrate for ultrasonic cleaner

#### Properties:

EM-404 removes mineral residue, flash rust, Grease, polishing and combustion residue from metal, light metal (motor blocks, carburettor, etc.), glass and plastic.

Quick and material-protecting cleaning is warranted at proper application.

#### Application:

Dosing depends on the degree of soiling and filling volume: 1-5% EM-404 for 5-20 min at 50-60°C. Use in stainless steel tray only. Upon completion: Flush cleaned goods thoroughly with water.

#### Composition:

Non-ionic surfactants, citric acid, corrosion protection. Biodegradable. Phosphate-free. pH-value of the 1%-solution: 3.0.

#### Marking according to hazardous substance regulation:

H318 Causes serious eye damage. P280 Wear protective gloves/protective clothing/eye protection/face protection.

P305+P351+P338 IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.



**Article: 61009**

**CPNP reference: 1331830**

Available in 500ml bottles – 2-litre or 5-litre canister

- We reserve the right to make technical changes! -